

Work Order ID 69443

Wednesday, May 11, 2011 10:31:17 AM



Page 1

Item ID: D206-642-511

Accept



Setup Start



Revision ID:

Stop



Item Name: Float Skidtube LH

Start Date: 5/11/2011 Start Qty: 1.00



Cust Item ID:

Required Date: 6/6/2011 Req'd Qty: 1.00

Customer:

Reference:

Approvals:

Process Plan:

[Signature]

Date: 11-05-11

Tooling:

Date:

Run Start



QC:

Date:

SPC (Y/N):

Date:

Stop



Sequence ID/ Work Center ID	Operation Description	Set Up/ Run Hours	Tool ID	Tool #	Plan Code	Accept Qty	Reject Qty	Reject Number	Insp. Stamp
--------------------------------	--------------------------	----------------------	---------	--------	--------------	---------------	---------------	------------------	----------------

Draw Nbr

Revision Nbr

INN-D206-642

Rev M

100

0.00



DOCUMENT CONTROL

DC

Memo

0.00

Document Control

Photocopy bluefile and create labels per PPP D206-642-511CHG004

Suloriz

CK for BA 11/07/20

110

Pick Kit

0.00



Packaging

Memo

0.00

Packaging

Luip/12 @

120

QC4- 100% Inspect kits for completeness

0.00



QC

Memo

0.00

Quality Control

Suloriz

B72036

W/O:		WORK ORDER CHANGES					
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector

Part No: _____ PAR #: _____ Fault Category: _____ NCR: Yes No DQA: _____ Date: _____

Resolution: _____ Disposition: _____ QA: N/C Closed: _____ Date: _____

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Chief Eng	Approval QC Inspector
			Initial Chief Eng	Action Description Chief Eng	Sign & Date			

NOTE: Date & initial all entries

Work Order ID 69443

Page 2

Wednesday, May 11, 2011 10:31:17 AM

Item ID: D206-642-511

Accept



Setup Start



Revision ID:

Stop



Item Name: Float Skidtube LH

Start Date: 5/11/2011 Start Qty: 1.00



Cust Item ID:

Required Date: 6/6/2011 Req'd Qty: 1.00



Customer:

Reference:

Approvals: Process Plan: _____ Date: _____ Tooling: _____ Date: _____

Run Start



QC: _____ Date: _____ SPC (Y/N): _____ Date: _____

Stop



Sequence ID/ Work Center ID	Operation Description	Set Up/ Run Hours	Tool ID	Tool #	Plan Code	Accept Qty	Reject Qty	Reject Number	Insp. Stamp
130 Packaging	Packaging	0.00							
Packaging	Memo	0.00							
Packaging	Identify and pack for shipping as per PPP D206-642-511 Location: _____								
		ReoF							
140 QC	QC21- Final Inspection - Work Order Release	0.00							
Quality Control	Memo	0.00							

P4/8/12

CK 11/08/12

ME

11-08-12

W/O:		WORK ORDER CHANGES					
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector

Part No: _____ PAR #: _____ Fault Category: _____ NCR: Yes No DQA: _____ Date: _____

Resolution: _____ Disposition: _____ QA: N/C Closed: _____ Date: _____

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Chief Eng	Approval QC Inspector
			Initial Chief Eng	Action Description Chief Eng	Sign & Date			

NOTE: Date & initial all entries

Picklist Print

Wednesday, May 11, 2011 10:31:23 AM

Page 1

Work Order ID: 69443



Parent Item: D206-642-511



Parent Item Name: Float Skidtube LH

Start Date: 5/11/2011

Required Date: 6/6/2011

Start Qty: 1.00

Required Qty: 1.00

Comments:

IPP Rev:B 05.09.23 Revised per D206-642 Rev. J KJ/JLM
 IPP Rev:C 07-02-23 As per IIN D206-642 Rev K JLM
 IPP rev D 07.06.06 added K642-511 EC
 IPP Rev:E 07-12-05 ECN 1080p Rev L DD verified by:

Component Item ID/ Item Name	Replacement Item ID	Mfg/ Purch	Bin Item	Primary Location	Last Location	Route Seq ID	Unit of Measure	Qty on Hand	Qty per Kit	Total Qty	Qty Issued	Date Issued	Status
---------------------------------	------------------------	---------------	-------------	---------------------	------------------	-----------------	--------------------	----------------	-------------	--------------	---------------	----------------	--------

D206-642-541

Manufactured

No

120

Each

1.0000

1

1



Replacement Skidtube



72036

CU

Location

Loc Qty

Loc Code

FG073

1

34772

1

K642-511

Manufactured

No

120

Each

0.0000

1

1



saddle kit 642-511



71500

CU 4/12

W/O:		WORK ORDER CHANGES					
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector

Part No: _____ PAR #: _____ Fault Category: _____ NCR: Yes No DQA: _____ Date: _____

Resolution: _____ Disposition: _____ QA: N/C Closed: _____ Date: _____

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Chief Eng	Approval QC Inspector
			Initial Chief Eng	Action Description Chief Eng	Sign & Date			

NOTE: Date & initial all entries